

## Inkopplingsanvisning LS600 -12XXX-01C (Grundutförande)

### Digital ut

<u>Adress /Plint</u>	<u>Förkortning</u>	<u>Typ</u>	<u>Beskrivning</u>
01/44	DO 1		
02/48	DO 2		
03/52	DO 3		
04/53	DO 4		
05/04	DO 5		
06/08	DO 6		
07/12	DO 7		
08/13	DO 8		

### Digital in

<u>Adress /Plint</u>	<u>Förkortning</u>	<u>Typ</u>	<u>Beskrivning</u>
01/55	DI 1		
02/57	DI 2		
03/59	DI 3		
04/60	DI 4		
05/15	DI 5		
06/17	DI 6		
07/19	DI 7		
08/20	DI 8		

### Analog ut

<u>Adress /Plint</u>	<u>Förkortning</u>	<u>Typ</u>	<u>Beskrivning</u>
01/63	AO 1	0-10V	
02/64	AO 2	0-10V	
03/67	AO 3	0-10V	
04/68	AO 4	0-10V	
05/23	AO 5	0-10V	
06/24	AO 6	0-10V	
07/27	AO 7	0-10V	
08/28	AO 8	0-10V	

### Analog in \*

<u>Adress /Plint</u>	<u>Förkortning</u>	<u>Typ</u>	<u>Beskrivning</u>
01/70	AI 1	1000 $\Omega$	* Vid beställning kan 0-10 V eller 1000 $\Omega$ väljas som ingångstyp. (Gäller samtliga analog ingångar.)
02/72	AI 2	1000 $\Omega$	
03/75	AI 3	0-10 V	
04/76	AI 4	0-10 V	
05/30	AI 5	1000 $\Omega$	
06/32	AI 6	1000 $\Omega$	
07/35	AI 7	0-10 V	
08/36	AI 8	0-10 V	

### LARMIA CONTROL AB

POSTADRESS  
Box 83  
SE-191 22 Sollentuna  
SWEDEN

BESÖKSADRESS  
Visiting address  
Aniarpplatsen 4, 3tr

LEVERANSADRESS  
Shipping address  
Allfarvägen 3  
SE-191 47 Sollentuna

TELEFON  
Telephone  
08-444 53 00  
+46 8 444 53 00

TELEFAX  
Facsimile  
08-444 53 19  
+46 8 444 53 19

EMAIL  
Info@larmia.se  
Website  
www.larmia.se

# Inkopplingsanvisning

## LS600-12XXX-01C

RUM A

RUM B

